




NEXA ZED2651/2951 WIRELESS 2D BARCODE SCANNER
— make scanning easy



Parts Instruction




Receiver Pairing



Scan the "Receiver Pairing Code" on the base
Factory Default: barcode scanner paired with base


Indicator Description



Indicator Type	Details Description
Battery	Four bars, charging flash
Wireless status	Bluetooth/2.4G connection
Pairing	Bluetooth/2.4G quick flash
Scanner ring light	One flash for one successful scanning
Base ring light	One flash for one successful data transferring Slow flash for pairing mode

Product Introduction

This is the simple user's manual, for detailed manual, please download from our website or contact the supplier. (With * is the Default Setting)




Factory Default


If scanner cannot be used normally due to an error setting, try to scan the "Factory Default" code above.

Voice Type	Details Description
One medium long high voice	Successful scanning or pairing
Three continuous short voice	Alarm prompt


Wireless Transmission Mode




*2.4G



Bluetooth




Bluetooth BLE




Bluetooth SPP


Data Transfer Mode




*Immediate mode




Inventory mode



Clear all data




Upload data




Upload all data

Interface Type




*USB-HID




USB Virtual Com Port
(Driver is needed for USB Virtual Com Port)


Sleep Time




Sleep Immediately



*1 min




5 min




30 min


Language




*USA




France



Germany




Turkey Q




Poland


Language




Brazil



Italy




Spain




Universal language

*For more languages setting, please refer to the full manual.


Terminator




NONE




*CR



LF




TAB




CR/LF

Receiver Pairing




2.4G Receiver Pairing

Scanning the "Receiver Pairing" code, scanner will enter the automatic pairing mode for 1 minute, then re-insert the receiver to the host. There will be a sound heard when pairing successfully.



Bluetooth HID Pairing

Scan the "Bluetooth HID Pairing" barcode, the scanner is ready to be connected by other bluetooth devices.



Scanner Version Information